


Machine Learning for IoT

LAB2: Pre-processing

LAB1-2: Smart Battery Monitoring (Simplified)



LAB2 Content

- Timeseries Processing:
 - Compression
 - Retention
 - Aggregation
- Audio Processing:
 - Resampling
 - Discrete Fourier Transform
 - Short-Time Fourier Transform
 - Mel Spectrogram
 - Mel-Frequency Cepstral Coefficients

LAB2 Content

- **Timeseries Processing:**
 - **Compression**
 - **Retention**
 - **Aggregation**
- **Audio Processing & Feature Extraction:**
 - Resampling
 - Padding
 - Normalization
 - Fourier Transform
 - Short-Time Fourier Transform
 - Log-Mel Spectrogram
 - Mel-Frequency Cepstral Coefficients




Covered in lectures

Timeseries Processing

Redis TimeSeries Memory Model

- A Redis TimeSeries consists of a list of linked chunks
- Each chunk contains
 - Header
 - Information needed by Redis to manage the data
 - A set of Records
 - Each record consists of:
 - Timestamp: 64-bit (8 bytes)
 - Value: 64-bit (8 bytes)
- Chunk size is set when creating the TimeSeries
 - Default: 4 KB
 - Smaller → Less Memory, Slower Read/Write
 - Larger → More Memory, Faster Read/Write



TimeSeries Compression

- Lossless compression
 - Gorilla algorithm

Timestamp Compression:

Time	Δ	$\Delta\Delta$

5000	5000	
10000	5000	0
15000	5000	
20000	5000	0

Value Compression:

t (s)	double	XOR
25	0x41c80000	0x00000000
25	0x41c80000	
25.5	0x41c00000	0x00040000
26.625	0x41d50000	0x00130000
26.14	0x41d11eb8	0x00043333

TimeSeries Compression



- Lossless compression
 - Gorilla algorithm
- Memory savings:
 - Depends on data
 - Best-case: 98.4%
 - Worst-case: 113.3%
 - Memory increases! But rare.
 - Average-case: 90.0%
- Compression improves performance due to a lower number of memory accesses
- **Note:** Compression is active by default

Example

- Which is the memory usage to store temperature every 5 seconds after 1 month?
 - 1 month = 30 days * 24 hours * 60 minutes * 60 seconds = 2592000 seconds
 - # of records = 2592000 / 5 = 518400
 - Uncompressed Memory $\approx 518400 * 16 \text{ bytes} = 8294400 \text{ bytes} = 7.910 \text{ MB}$
 - Compressed Memory $\approx 7.910 \text{ MB} - 90\% = 0.791 \text{ MB}$
- Approximations:
 - We neglected the header size
 - We neglected that the memory usage is always a multiple of the chunk size
 - We considered the average compression ratio

TimeSeries Aggregation

- Lossy Compression
- Aggregation Parameters:
 - Bucket Duration
 - Aggregation type: avg, sum, min, max, range, count, first, last.
- **Note:** Aggregation never changes the original timeseries but creates a new one



TimeSeries Retention

- You can prevent your timeseries growing indefinitely by setting a maximum age for samples compared to the last event time (in milliseconds).
- By default, retention is 0
 - i.e., the timeseries will be never trimmed