

Machine Learning for IoT

Lab 2 – Pre-processing

Exercise 1: Timeseries pre-processing

- 1 On the RPI, continuously run the T/H monitoring script developed in *LAB 1 – Exercise 2*.
- 2 Set the following retention rules on your Redis TimeSeries database:
 - a. Set the retention period of the *mac_address:temperature* and *mac_address:humidity* timeseries to 1 day.
 - b. Create two timeseries with a chunk size of 128 bytes, called *mac_address:temperature_avg* and *mac_address:humidity_avg*, that store the average over every 30s of *mac_address:temperature* and *mac_address:humidity* , respectively. Set the retention period of the two timeseries to 30 days.
 - c. Create a timeseries with a chunk size of 128 bytes, called *mac_address:temperature_min*, that stores the minimum over every 1 minute of *mac_address:temperature* . Set the retention period of the timeseries to 30 days.
 - d. Create a timeseries with a chunk size of 128 bytes, called *mac_address:temperature_max* that stores the maximum over every 1 minute of *mac_address:temperature* . Set the retention period of the timeseries to 30 days.
 - e. For all the timeseries, check the number of samples and their memory size after at least 15 minutes of monitoring.
 - f. Repeat the steps a., b., c., and e., disabling compression (create new timeseries for each step adding “_uncompressed” to the original names). Report the results in the following table and discuss the collected statistics:

Timeseries Name	# of Samples	Compressed Size (KB)	Uncompres. Size (KB)
<i>mac_address:temperature</i>			
<i>mac_address:humidity</i>			
<i>mac_address:temperature_avg</i>			
<i>mac_address:humidity_avg</i>			
<i>mac_address:temperature_min</i>			
<i>mac_address:temperature_max</i>			

- g. For each timeseries, estimate the maximum number of samples and the maximum memory size, considering both the compressed and the uncompressed versions. Report the results in a table.
 - h. Plot the created timeseries in Deepnote.

Exercise 2: Profiling Audio Features Extraction on the edge

1. On the RPI, create and run a script to measure the execution time (i.e., the latency) needed to process audio feature extraction methods.
 - a) Download to the RPI the *preprocessing.py* script from Deepnote. Store the script in your working directory.
 - b) Use the script *lab2_ex2.py* (available in the Portale della Didattica, under the folder *Labs/lab2-preprocessing*) to measure the latency for computing the spectrogram.
 - c) Modify the script to measure the latency for processing the log-Mel Spectrogram and MFCC.
 - d) For all the three feature extraction methods, try different hyperparameters values in the following ranges
 - STFT frame length $\in [10, 50]$ ms. Try also with power-of-two values like 8ms, 16ms, 32ms, and comment the results.
 - STFT frame step such that overlap $\in \{0\%, 25\%, 50\%, 75\%\}$.
 - # of mel bins $\in [10, 128]$.
 - Mel lower frequency $\in [0, 80]$ Hz.
 - Mel upper frequency $\in [2000, 8000]$ Hz.
 - # of MFCCs $\in [10, \text{\# of mel bins}]$.
 - e) Report the collected values in a table, following this template:
 - f) Discuss the collected results.

Method	Hyperparams values	Latency (ms)
Spectrogram	frame_length=10, frame_step=50%	
Spectrogram	frame_length=10, frame_step=75%	
MelSpectrogram	...	
MFCC	...	
...	...	